

INSTRUCTIONS FOR OIL AND GAS FLOODPLAIN DEVELOPMENT
No development can occur in the floodplain until permit is issued.

Fill out and sign the permit application form (all pages).

Permit fee is \$500.00; make check payable to Burleson County.

Include with permit application:

- Detailed set of plans and specifications, including flood-proofing measures designed by a licensed engineer.
- Copies of other required permits including those from the Texas Railroad Commission (permit to drill) and 404 permit from US Army Corps of Engineers (if needed).
- Copy of Spill Prevention and Counter Measure Plan.
- Emergency Evacuation Plan in case of imminent flood event.

All structures and pieces of equipment in the 1% chance/100-year floodplain must be flood-proofed (designed in a manner to reduce or eliminate flood damage, e.g. anchoring) or elevated.

A base flood elevation (BFE) must be established and elevation and/or flood-proofing of equipment must be to the BFE.

Flood-proofing measures must include the following: 1. Tank batteries and other equipment installed at the site in the floodplain shall be tied down to prevent flotation and lateral movement. 2. Protection around any vulnerable equipment such as the well head must be installed to keep flood debris from damaging equipment which could release product into floodwaters or send equipment floating downstream.

Pipelines must be buried at least 48 inches, 72 inches under rivers and creeks. A statement acknowledging this is required.

A closed pit system is required.

Any material stored on the site that is highly volatile, flammable, explosive, toxic or water reactive should be protected to at least the level of the 500-year flood.

Drill site pad and road to well do not need to be elevated but should not obstruct the natural flow of water (i.e. install culverts and flood control devices as needed). A culvert must be installed in the barrow ditch where the lease road meets the county road.

Tree and brush debris must be removed for the floodplain or burned.

After drilling is completed and site is built, **flood-proofing certificates for all flood-proofed equipment and structures, signed by a licensed engineer, must be submitted.** Submit elevation certificate if anything was elevated above the BFE. The floodplain administrator will inspect the site again at this time.

The developer shall provide a list of equipment installed at site after completion. This office must be notified if equipment is added after completion. If site is sold or assigned this office must be notified. A recomplete will only need a permit if new production equipment is added to an existing site.

For assistance, please contact (979) 567-2001.